



38"X19" RECTANGULAR GRILL TABLE

ASSEMBLY INSTRUCTION

ITEM#: H22ST1122 SKU# 810588213

Need help? We are here for you! 1(877)800 – 6021 • Toll Free service@hcipatio.com • Email Address

GENERAL BEST PRACTICES FOR ASSEMBLY:

- Read all instructions before starting.
- Clear a flat covered space to begin assembly.
 - Always best to do it with a friend.
- Note that hardware required is provided for every step.
 - Pay attention to orientation.
- Letter of the part corresponds to a sticker on the product.
- Number of the hardware corresponds to its letter in the package.
 - Helpful hints provided along the way.
 - Retain these assembly instructions for future reference.


WARNINGS:

- · Regularly check hardware and tighten if necessary.
- Use the correct bolts as indicated. Do not tighten any of the bolts until the table is completely assembled.
- Do not sit or stand on this table.
- · Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.
- Keep children away during assembly. This item contains small parts that can be swallowed by children.
 Children should always be under direct adult supervision while using this product.
- Table is not to be used as a seating surface. Improper use of this product may result in injury.

MAINTENANCE:


- Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame parts.
- Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your table.
- When moving the table, lift. Do not drag this table.
- We recommend the use of furniture covers when not in use.
- In order to prolong the life and beauty of your table, we recommend that it be stored in a dry and protected area during off season periods.

PARTS LIST							
PART NO.	MATERIAL CODE	PART	Q'TY	PART NO.	MATERIAL CODE	PART	Q'TY
1	HTMS38MB-YJG	RIGHT LEG	1	14	HTMS38MB-KPQ	BOTTLE OPENER	1
2	HTMS38MB-ZJG	LEFT LEG	1	15	htms38mb-ljj	LOWER CONNECTOR	2
3	HTMS38MB-ZM	TABLE TOP	1	16	LS-M6-35	BOIT M6*35	8
4	HTMS38MB-SK	TOPFRAME	1	17	LS-M6-30	BOIT M6*30	3
5	htms38mb-jk	REAR FRAME	1	18	LS-M6-1 <i>5</i>	BOIT M6*15	20
6	HTMS38MB-DG	BOTTOM FRAME	1	19	ZGLS-ST4.2-15	SCREW ST4.2*15	10
7	HTMS38MB-ZKB	CROSS BRACE	1	20	DP-d6.5-D13	WASHER d6.5*D13*1.0	27
8	HTMS38MB-ZKA	BRACE FRAME	1	21	HTMS38MB-ZG	SUPPORT	1
9	HTMS38MB-ZMK	LEFT DOOR	1	22	HTMS38MB-BS	HANDLE	1
10	нтмѕз8мв-үмк	RIGHT DOOR	1	23	LS-M6-45	BOIT M6*45	2
11	HTMS38MB-ZWH	вох	1	24	LM-M6	JAM NUT M6*1.0	2
12	НТМЅЗ8МВ-ЏЈА	CENTER CONNECTO A	1	25	HTMS38MB-HL	WHEEL	2
13	HTMS38MB-LJJB	CENTER CONNECTO B	1	26	HTMS38MB-ZMZG	TABLE TOP SUPPORT	1






PARTS REQUIRED: 1, 2, 4, 18, 20, 23, & 24 Keep the bolts loose.











STEP 2


PARTS REQUIRED: 1, 2, 5, 18, & 20 Keep the bolts loose.








PARTS REQUIRED: 1 & 7



STEP 4


PARTS REQUIRED: 4, 5, 7, 8, 17, & 20 Keep the bolts loose.







PARTS REQUIRED: 1, 2, 6, 16, & 20 Keep the bolts loose.








STEP 6

PARTS REQUIRED: 1, 2, 4, 9, 10, 15, 18, & 20 Keep the bolts loose.








PARTS REQUIRED: 3, 19, & 26

Tighten all bolts by using the supplied Hex key.






STEP 8

PARTS REQUIRED: 1, 2, 3, 18, & 20

Tighten all bolts by using the supplied Hex key.








PARTS REQUIRED: 11, 12, 13, & 19

Tighten all bolts by using the supplied Hex key.











STEP 10

PARTS REQUIRED: 1 & 16






PARTS REQUIRED: 11



STEP 12

PARTS REQUIRED: 21




PAGE 8 OF 10

PARTS REQUIRED: 2, 18, 20, & 22

Tighten all bolts by using the supplied Hex key.








STEP 14

PARTS REQUIRED: 2, 14, & 18
Tighten all bolts by using the supplied Hex key.







Warranty

- · One-year limited warranty.
- · Proof of purchase (dated register receipt) is required for warranty claims.
- · It remains the customer's responsibility for freight and packing charges to and from the service center.

STOP!

Missing A Part? No Need To Go Back To The Store

The store where you made your purchase does not stock parts for this item. If you need parts, whether they are missing or damaged,

Call Toll Free:

TEL: 1-877-800-6021

Call us between 9:00 AM and 4:30 PM Eastern Time Monday through Friday For further assistance, please visit us at service@hcipatio.com