



3-TIER GREENHOUSE

ASSEMBLY INSTRUCTIONS

ITEM# GB-ML1301

SKU# 810594880

DO NOT RETURN THIS PRODUCT TO THE STORE. FOR MISSING PARTS OR QUESTIONS TO THIS PRODUCT PLEASE CALL US AT 1-888-733-8169
OR EMAIL US AT customerservice_01@yeah.net OR customerservice_02@yeah.net OR customerservice_03@yeah.net

IMPORTANT:

Ensure you read and fully understand instructions before use.

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.








WARNING:

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- This product is intended for outdoor use only. It is strongly recommended to store the product during heavy weather conditions of strong wind or rain as both can cause damage to the product and put you and others in potential danger.
- This product is designed and intended for commercial and recreational use. Prolonged exposure to UV rays will cause any fabric to fade and deteriorate and is NOT covered by this 1 Year Limited Warranty.
- We suggest that you take your time in order to avoid bending the frame. Also to avoid pinching fingers or hands while opening and closing the frame.
- Select ideal location. Set out all parts on a clear and leveled surface prior to assembly. Avoid setting up your greenhouse on steep inclines.
- Do not use your greenhouse for permanent shelter. It is designed for temporary use only.
- Keep your greenhouse away from heat and flames at all times. Do not barbecue or build fires under your greenhouse.

CARE & MAINTENANCE

- Hand wash the canopy using only mild soap and water. Never use harsh detergents, abrasives or bleach. Do not machine wash fabric components.
- Never fold or store your greenhouse when it is wet or damp. Let it dry completely to avoid mildew.
- The frame MUST be staked or properly weighted down at all times.
- For best results in keeping your top clean and avoid small rips and tears, it is recommended that the top be removed from the frame and stored in the carry bag after each use.

PARTS LIST

NO.	Part	Qty	Image	NO.	Part	Qty	Image
A	Joiner	12		E	Roof tube	2	
B	Cross joiner	4		F	Shelf	3	
C	Vertical tube	12		G	Cover	1	
D	Cross tube	8					


Warranty

One-year limited warranty.

Proof of purchase (dated register receipt) is required for warranty claims.

It remains the customer's responsibility for freight and packing charges to and from the service center.

SET UP THE GREENHOUSE



Once assembled, slide the Cover (G) over the frame and secure with ties in the bottom.