

5FT. 105L MOVING WINGS ANGEL WITH FLUTE ASSEMBLY INSTRUCTIONS

Replacement:

Extra bulbs and
fuse included

Attached Parts

1.ring-1PCS



2.hair-1PCS




3.body-1PCS



4.arm-2PCS




5.wing-4PCS



6.hemline-2PCS



7.bottom-1PCS




8.belt-1PCS



9.flute-1PCS



10.Cotter pin-4PCS



11.Cable tie-10PCS



12.Ground Stakes - 4PCS



13.Fuse-1PCS



14.Bulbs-3PCS




FIG.1




FIG.2

(1) Carefully remove all of the parts from the box and place on a flat surface. Check the Parts List to make sure all of the parts are included.

(2) The rod on one half is inserted into the matching hole on the other half, then they are secured together and fastened with plastic (Part 11) Insert the upper body (Part 3) into the metal bar of the hemline and fasten it with plastic (Part 11)(see Figure 1/2)




FIG.3



FIG.4

(3) Insert the white wings into the holes of the gold wings (Part 5) and secure them together with plastic ties (FIG.3)

(4) Place the wings (Part 5) by inserting the rods into the metal holes in the back of the angelic body (Part 3) and securing them with cotter pins (Part 10) (FIG.4)




FIG.5



FIG.6

(5) Insert the rods of each arm (Part 3) into the corresponding holes in the upper body. (See Figure 3) Insert the hair (Part 2) rod into the back of the metal hole in the head (Figure 5)

(6) Hold the flute (Part 9) in your hand so that it can be locked in place, tie the belt (Part 8) around the waist of the angel, finally insert the metal rod of the base into the cotter pin (Part 10), then into the hole at the bottom of the angel, and finally secure the plastic cable tie together (Part 11)




FIG.7

(7) Anchor angel to the ground by the ground stakes (Part 12). (See Figure 7)

(8) Plug in