


5FT(150CM) BRANCH TREE LED GLOBE LIGHTS

Thank you for purchasing this prelit tree. Carefully follow the instructions below on how to quickly and easily set up your new tree.

TREE ASSEMBLY INSTRUCTIONS

WARNING- Risk of personal injury and electric shock: Watch for any bulbs that may have broken during shipment and replace following the bulb replacement instructions before plugging in.

1. Before you start to assemble your tree, choose a location near a wall outlet.
2. Please place the tree pot on a level surface. Put the cement stand into the pot.



3. Each tree section has a letter tag. Please identify all sections before assembling.
4. Since you have the tree sections laid out in alphabetical order, we will start assembling from the bottom to the top.
5. Place the bottom section (A) into the pot. Next connect top section (B) into section (A), Lights see Fig. A1
6. Connect the lights strings as per the color labels indicated in **Fig.A** and insert green label plug (**see Fig. A2**) into the wall outlet. Your entire tree should now be lit. If some bulbs do not light or flicker, search for any loose plugs and/or broken, loose or missing bulbs. Replace bulbs promptly in order to maintain the performance and life expectancy of your pre-lit tree.

7.Begin to shape the branches and tips working from the bottom of the tree to the top. Branch tips will need to be spread in all directions for the tree to look full and thick. Slightly bending the very end of the outermost tips gives helps the appearance.

8.After shaping the whole tree, step back and take an overall look. The tree should have a full and even appearance. Additional shaping of some branches may be needed to fill in any gaps and give a uniform look. Your tree is now ready to decorate and enjoy!

CAUTION:IMPROTANT SAFETY INSTRUCTIONS

- 1.This tree is intended for indoor use. Do not use this product for other than its intended use.
2. Do not connect extra light sets, tree tops or any other electrical items to the existing light sets on your pre-lit tree.
3. This seasonal product is not intended for permanent installation or use.
4. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
5. Unplug power supply cord when replacing bulbs and fuses ,when leaving the house, when retiring for the night or if left unattended.
6. Never change fuse with the power supply cord plug in wall outlet.
7. Do not place near gas or electric heaters, radiators, fireplaces, candles, outdoor heaters, barbeques, similar sources of heat.
8. Place on a level, hard, flat surface, do not place where tree is likely to wobble due to uneven surfaces, floors or thick carpeting.
9. After assembling the tree and adding decorations, make sure the tree is stable. If tree is not stable, shift the weight of the decorations, and if used indoors, use support wires to walls and/or window frames(make sure they are secure also).
10. Do not install near fountains, bathtubs, sinks, pools, hot tubs, or other areas of standing water.
11. Do not use candles on tree.
12. Never operate this product if the power cord or plug is damaged.
13. Do not overload extension cords or power strips, see rating on those devices and check the rating label of the product for compatibility.
14. Use only manufacturer specified replacement bulbs.
15. This product employs an overload protection (fuse) in the plug of each light set. A blown fuse indicates an overload or short circuit situation. If the fuse blows, unplug the product from the power supply. Replace the fuse as per the replacement instructions indicated in this manual (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short circuit may be present and the product should be discarded.
16. This is an electrical product-not a toy! To avoid risk of fire, burns ,personal injury an electric shock it. Should not be played with or placed where small children and pets can reach it.

STORAGE

- 1.Unplug lights cord from the wall outlet and remove all ornaments and decorations.
- 2.Unplug each section.
- 3.Gently lift off the top and middle sections, and remove the bottom section from the tree stand. Carefully place the tree in its box and tape it shut.

DO NOT STORE TREE IN A DAMP AREA OR IN AN AREAWHERE THE TEMPERATURE EXCEEDS 100° F.

SKU#:810614477

Mfg No.:8147-H47709-02


2

Made In China


TROUBLE SHOOTING INSTRUCTIONS

If Lights Do Not Work:

1. Please check to make sure that all plugs are properly connected according to the color labels indicated in **Fig.A** and the power cord is plugged into the wall outlet. Refer to assembly guide for instructions.
2. Check whether all bulbs are tightly inserted into lamp holders and replace any missing or broken bulbs.
3. If a bulb is blown, replace the faulty bulb following the below diagram. There are spare bulbs Included for easy replacement.



4. If none of the lights are working, check the fuse in light string plug. If the fuse is blown, replace the blown fuse following the below diagram. There is a spare fuse included for easy replacement.



WARNING- Only use the included spare bulbs that are rated 3.0 Volt, 0.072 Watts .LED type lamp (provided with product).

WARRANTY INFORMATION

1. For a period of 1 year from the date of purchase, **The Original Christmas Factory.** will replace defective parts on the product at no charge except for shipping & handling.
2. This limited warranty applies to all components of the product.
3. This limited warranty does not cover damage resulting from accident, misuse, abuse, negligence, or normal wear.

To Obtain Warranty Service: You must notify **The Original Christmas Factory.**, by mail, of the nature and description of the defect, and enclose a copy of the original sales receipt.

Customer Service Email: biglots.service@kingtree.com