# Assembly Instructions for 62 Inch Animated Standing Buck Sculpture

Do not plug the light string into an outlet until this item is fully assembled and the light strings are properly connected. Please read the enclosed important safety instructions and cautions carefully prior to use.

#### **Enclosed Parts**

- \* 2 Antlers, 2 Ears, Head, Body
- 4 Legs, Tail, Bow
- \* 4 Lawn Stakes

## Spare Parts

- \* 2 3 Amp Spare Fuses
- \* 4 Spare Bulbs
- \* 5 Plastic Ties
- \* 1 5 Amp Spare Fuse (located inside the plug of the motor)

# Trouble Shooting

# If one section does not light

- 1. Replace any broken or loose bulbs.
- Check each bulb one at a time by removing it from its socket and replace it with a bulb that works.

## If no lights light up


- 1. Check your outlet to make sure you have power.
- 2. Check your extension cord to make sure it has power.
- 3. Check the fuse on the male plug of the light set.
- 4. Replace the fuse if it is blown, using a 3 amp fuse for the light string, 5 amp fuse for the motor.
- 5. Check for any broken or loose bulbs, replace any damaged bulbs with new ones.

## Instructions


- 1. Carefully remove item from the protective wrap, do not use a knife, to avoid damaging any of the light bulbs or parts.
- 2. Attach the 2 front legs and 2 back legs to the body by inserting the rods on the legs into the holes on the body. Then secure the front legs by inserting the hook on one of the front legs into the hole on the other front leg. Secure the back legs in the same manner.
- 3. Insert the tail on the back.

- 4. Attach the head to the body by inserting the rods into the holes at the top and the bottom.
- Then insert the connecting pole on the motor into the hole on the neck

- 5. Attach the 2 antlers and 2 ears by inserting the rods on the antlers and ears into the holes on the head.
- 6. Hang the bow on the neck.



- 7. Secure the item firmly into the ground by pushing the lawn stakes through the feet.
- 8. Connect the power cord on the unit to an UL listed extension cord.



**MODEL:D23001**