



ASSEMBLING INSTRUCTIONS


ITEM NO: 9304GRY-1 Push Back Reclining Chair

⚠ Legs stored in the box and located under chair seat bottom, please take out for assembly.
 It is recommended to install protective pads under all legs and supports to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.


PARTS LIST

NO.	DRAWING	QTY	DESCRIPTION
A		1 PC	SEAT
B		1 PC	BACK REST
C		2 PCS	WOODEN FRONT LEG
D		2 PCS	WOODEN REAR LEG


STEP 1:
 Please find the inner leg box under chair seat bottom.




STEP 2:



STEP 3:



STEP 4: COMPLETED



CARE INTRUCTION FOR PU FURNITURE

In order to maintain the original appearance of your PU furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage PU.
- Do not place your PU furniture too close to windows, radiators, or vents and be sure to use window, radiators, or vents.
- Vacuum or wipe with a cloth regularly to remove dust.
- For items used on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs supports to avoid/prevent from damages/scratches discoloration.