



SOLAR POWERED DECORATIVE LIGHTS ASSEMBLY INSTRUCTIONS

ITEM NO. ES99-742

1. Clip Assemble



2. Ground Stake Assembly



LIGHT CHARGING

For First Time Use: THE SOLAR CHARGING SYSTEM NEEDS TO CHARGE FOR 8-12 HOURS WITH THE SWITCH "ON". THIS ALLOWS THE RECHARGEABLE BATTERY TO REACH MAXIMUM CAPACITY. If the light does not turn on after 6-8 hours of charging, make sure the switch is in the "ON" position, check the battery to ensure that the +/- connectors match properly. Make sure the connectors are securely plugged in and making contact with the terminals

LIGHT ASSEMBLY

- To Mount Using Clip:** Unwind the light set and place the lights where you wish to locate them. (PLEASE NOTE: Make sure the solar panel will be installed where sunlight can reach it.) Attach the solar panel (Part A) by inserting the top of the clip (Part B) into the bottom of the solar panel (Part A). Then carefully secure the clip onto the location where you wish to place it. (PLEASE NOTE: The location should be strong enough to support the weight of the solar panel.)
- Ground Stake Assembly:** Attach the solar panel (Part A) to the ground stake (Part C) by inserting the top of the lawn stake (Part C) into the hole on the side of the solar panel (Part A). Carefully insert the ground stake (Part C) into the ground where desired. Push the stake into the ground until the top collar is even with the ground surface. (PLEASE NOTE: If the ground is hard and packed, moisten the ground with water before inserting the stake to avoid breakage.)

Replacing the Battery: Push the power switch to the "OFF" position. Remove the 8 screws from the bottom of the Solar Panel.

Remove the top section of the solar panel. Then carefully pull up the battery without disconnecting or breaking any wires. Remove the old battery and replace with 1 new AA 600mAh 1.2V Ni-MH battery. (NOTE: Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-Zinc) or rechargeable (Nichel-Cadium) batteries). Replace the top section and secure with the 8 screws.

Push the power switch to the "ON" position. Allow Battery to recharge in full sunlight for 8 - 12 hours.

IMPORTANT:

- The solar panel must be placed in a well-lit location for maximum sunlight absorption
- Anything that shades this panel will affect the brightness and lighting duration
- 8-12 hours of light exposure are required for adequate illumination
- Charge battery using solar panel for at least 8 - 12 hours before first use.
- Always purchase the correct size and grade of battery most suitable for the intended use
- Replace all batteries of a set at the same time
- Clean the battery contacts and also those of the device prior to battery installation
- Replace batteries ensuring proper polarity
- remove battery promptly if consumed and if product left unused for long time
- Do not dispose of this product in fire, the batteries inside may explode or leak
- Replace only with 1AA type charge batteries

DO NOT DISPOSE OF OLD BATTERIES - PLEASE RECYCLE THEM AT APPROPRIATE BATTERY RE-CYCLE CENTER

Caution:

Change or Modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Everstar Merchandise Co., Ltd
7180 Troy Hill Drive, Suite E, Elkridge, MD 21075
1-800-833-3390
Product Name: SOLAR POWER 15 LED MULTI G40 BULB LIGHT SET
Model No: ES99-742
SKU# 810588502